Small genome de novo assembly

A plant mitochondrial genome, whose size is 500,000 bp

How can you get mitochondrial DNA? What problems do we need to concern for this step?

- Two options:
- (1) get mitochondrial DNA only (grow your plant in a dark room)
 - (2) get total DNA

Paired-end or single end sequencing?

 Paired-end sequencing is necessary for scaffolding and good quality.

- For DNA fragmenting, what size of DNA fragments will you use? (or insert size of paired-end sequencing)
 - A. 800bp
 - B. 1Kbp
 - C. 5Kbp
 - D. use all above

Usually, 1Kbp is enough.

coverage

 What coverage do you sequence? How many reads do you need to get for this coverage? How many lanes do you need if you use Illumina Hi-Seq 2000? Hi-Seq 2000 has 200-400 million paired-reads (100bp) per lane.

Coverage = 100x

Coverage = NL/G

N=coverage*G/L=100x500Kbp/100bp=500K

5% of total DNA is mitochondrial DNA, then we need 20 x 500K reads

Which assembler will you use?

Velvet for small genomes

- What computer do you used to do assembly?
 - A. 4GB laptop
 - B. 20GB workstation
 - C. computer cluster in HCC

- According to your estimate, how long does it take for assembling?
 - A. 30 minutes
 - B. 1 hours
 - C. 10 hours
 - D. 4 days

What software do you used for scaffolding? how long does it take?

- Velvet or SSPACE
- Couple hours are enough

What is longest gap in one scaffold? How do you fill gaps?

- If we use 1kbp insert-size library for pairedend sequencing, the longest gap is around 1kbp.
- PCR is enough

How do you determine if your assembled genome is good enough?

- See if it is circular. If we do not get a circular genome, we may consider to have an additional library with a different insert size.
- Compare with known mitochondria genome

How do you annotate genes?

- Using existing software tools, such as Dogma,
 ORF finder, or T-RNA scan.
- Collect all known mitochondria genes, and use BLAST to search the assembled mitochondria genome against these known genes.